禪

[illegible]

-30
-40
-50
-60
-70
-80
-90
Signal Strength [dBm]
2437s
2442s
2462s
2467s
2422s
2412s
1 2 3 4 5 6 7 8 9 10 11 12 13 14
Wifi Channels

[illegible]

[illegible]

- [illegible]
- [illegible]
- [illegible]
- [illegible]

[illegible]

:1 [illegible]

[illegible] **inSSIDer utility** . [illegible] WiFi Analyser [illegible].

.11 ו 1ו6 ,ערוצים שני לפחות בהם יש אם ,ערוץ באותו נמצאים שלא רשתות בין הפרעות למנוע כדי

:2 שלב

.WiFi Analyser באפליקציית שימוש ידי על בסביבה הקיימות הרשתות כל את לזהות ניתן

:3 [illegible]

Administrator: Command Prompt
Microsoft Windows [Version 6.3.9600]
(c) 2013 Microsoft Corporation. All rights reserved.
C:\Windows\system32>ipconfig
Windows IP Configuration
Wireless LAN adapter Local Area Connection* 3:
Media State . . . . . : Media disconnected
Connection-specific DNS Suffix . :
Wireless LAN adapter WiFi:
Connection-specific DNS Suffix . : domain.name
Link-local IPv6 Address . . . . . : fe80::60f5:83e8:84e9:b521%6
IPv4 Address. . . . . : 192.168.10.26
Subnet Mask . . . . . : 255.255.255.0
Default Gateway . . . . . : 192.168.10.1
Ethernet adapter Ethernet:
Media State . . . . . : Media disconnected
Connection-specific DNS Suffix . :
Tunnel adapter isatap.domain.name:
Media State . . . . . : Media disconnected
Connection-specific DNS Suffix . : domain.name
Tunnel adapter Teredo Tunneling Pseudo-Interface:
Connection-specific DNS Suffix . :
IPv6 Address. . . . . : 2001:0:d59:2ec8:38d2:3ac9:3f57:f5e5
Link-local IPv6 Address . . . . . : fe80::38d2:3ac9:3f57:f5e5%9
Default Gateway . . . . . : ::
C:\Windows\system32>

DIGICOM
zing series
Firmware ver. Z-2.1
Login

Username: admin
Password: •••••

Login

Software : Firmware version : Z-2.1
2013 © All Rights Reserved
DIGICOM FUTURISTIC TECHNOLOGIES LIMITED
HONG KONG

بعد از وارد کردن آدرس ایپی روتر در مرورگر وارد صفحه اطلاعات ورود به رابط کاربری تنظیمات روتر میشوید. اگر قبلا نام کاربری و کلمه عبور خود را تغییر نداده باشید میتوانید با وارد کردن نام کاربری و کلمه عبور پیش فرض admin (در اکثر روترها) (   ) وارد صفحه تنظیمات شوید.

مرحله 4:

DIGICOM
zing series
Firmware ver. Z-2.1
DG-5624T
Setup
Wireless
Advanced
Maintenance
Status
Help
Wireless Basics
Guest Network
WPS
Wireless Advanced
Wireless Repeater

Wireless Basics

This page is used to configure the parameters for wireless LAN clients which may connect to your Access Point. Here you may change wireless encryption settings as well as wireless network parameters.

Wireless Network

Enable SSID Broadcast: ☑
Enable Wireless Isolation: ☐
Name (SSID) : goli_net
Mode : 802.11b/g/n
Channel: Auto Current Channel: 11
Band Width : Auto 20/40M

Security Options

Security Options : WPA-PSK/WPA2-PSK AES

Security Options(WPA-PSK+WPA2-PSK)

Pre-Shared Key: abd17hsirah (8-63 characters or 64 hex digits)

Apply
Cancel

Helpful Hints...

NOTE: To ensure proper agency compliance and compatibility between similar products in your area, the operating channel and region must be set correctly.

Placement of the Router to Optimize Wireless Connectivity

The operating distance or range of your wireless connection can vary significantly based on the physical placement of the router. For best results, place your router:

- Near the center of the area in which your PCs will operate.
- In an elevated location such as a high shelf.
- Away from potential sources of interference



بعد از ورود به رابط کاربری صفحه مربوط به تنظیمات Wireless را انتخاب و از بخش Channel کانال مورد نظر خود را انتخاب کنید . تصویر بالا صفحه تنظیمات Wireless روتر Digicom را نشان میدهد که در وسط صفحه بخش مربوط به تغییر کانال قرار دارد .

DIGICOM
zing series
Firmware ver. Z-2.1
DG-5624T
Setup
Wireless
Advanced
Maintenance
Status
Help
Wireless Basics
Guest Network
WPS
Wireless Advanced
Wireless Repeater
Apply
Cancel

Wireless Basics

This page is used to configure the parameters for wireless LAN clients which may connect to your Access Point. Here you may change wireless encryption settings as well as wireless network parameters.

Wireless Network

Enable SSID Broadcast: ☑
Enable Wireless Isolation: ☐
Name (SSID) : goli_net
Mode : 802.11b/g/n
Channel: 11 Current Channel: 11
Auto 1 2 3 4 5 6 7 8 9 10 11 12 13
Band Width : 40M

Security Options

Security Options : WPA2-PSK AES

Security Options(WPA-PSK+WPA2-PSK)

Pre-Shared Key: (8-63 characters or 64 hex

Helpful Hints...

NOTE: To ensure proper agency compliance and compatibility between similar products in your area, the operating channel and region must be set correctly.

Placement of the Router to Optimize Wireless Connectivity

The operating distance or range of your wireless connection can vary significantly based on the physical placement of the router. For best results, place your router:

- Near the center of the area in which your PCs will operate.
- In an elevated location such as a high shelf.
- Away from potential sources of interference

بعد از انتخاب شماره کانالی که فکر میکنید بهترین نتیجه را برای شما به همراه خواهد داشت یک بار روتر را ریبوت کنید تا تغییرات اعمال شود .

نویسنده :
محسن آقاجانی
منبع :
nswits
دسته بندی:
ترفند اینترنت و وایفای
تاریخ انتشار :
09:45 - 02/11/1395
برچسب:
تغییر کانال روتر - وایفای - روتر بیسیم - ترفندهای وایفای - مدیریت وایفای - تنظیمات روتر

نشانی
https://www.shabakeh-mag.com/networking-technology/6439/%DA%86%DA%AF%D9%88%D9%86%D9%87-%DA%A9%D8%A7%D9%86%D8%A7%D9%84-%D9%88%D8%A7%DB%8C%E2%80%8E%D9%81%D8%A7%DB%8C-%D8%B1%D9%88%D8%AA%D8%B1-%D8%AE%D9%88%D8%AF-%D8%B1%D8%A7-%D8%AA%D8%BA%DB%8C%DB%8C%D8%B1-%D8%AF%D9%87%D9%8A%D9%85:□□□□